

## INSTALLATION NOTES:

- DISCONNECT AC POWER TO WINDSOCK POLE.
- DISCONNECT POWER CORD AT POLE BASE.
- REMOVE & DISCARD EXISTING INCANDESCENT SOCKET ASSY., OBS LIGHT, AND POWER CORD.
- LED KIT INSTALLS WITHOUT REMOVING ITS PLATES.
- HAVE AN ASSISTANT HOLD THE LED PANEL AND OBS BOX ASSY., TO AVOID TWISTING STRAIN ON THE LIQUID TIGHT CONDUIT AND CONNECTORS, WHILE SLIDING THE NEW POWER CORD DOWN THE MAST.
- MOUNT OBS BOX SWIVEL ASSEMBLY ON THE PIPE.
- POSITION PANEL SO SUB PANELS ARE SIDE BY SIDE.
- THE LIQUID TIGHT CONDUIT CONNECTOR, ON THE PANEL, MUST BE IN UPPER RIGHT HAND CORNER.
- U-BOLT THE PANEL BAR ENDS TO THE BASKET CAGE.
- POSITION LIQUID TIGHT CONDUIT SO THERE IS A WATER DRIP LOOP NEAR THE PANEL.
- ENSURE THAT CONDUIT DOESN'T RUB ON THE PIPE.
- ALL HARDWARE ON THE PANEL AND LIQUID TIGHT CONNECTORS ARE FACTORY SILICONE SEALED. REMOVAL OF ANY HARDWARE WILL BREAK THE SEAL...WATER ENTRY WILL DESTROY LED PANELS AND VOID WARRANTY. REPLACEMENT COST IS \$1,600.

