






South St. Paul Municipal Airport - Fleming Field

Airport Safety Zones

Date: 08/08/2018



Legend

-  Zone A
-  Zone B
-  Zone C
-  ERN

DISCLAIMER: This is not an official zoning map. To view the official map and ordinance for this airport, please visit the Airport Zoning Information Warehouse at <https://www.dot.state.mn.us/aero/planning/zoning-warehouse.html>. The State of Minnesota makes no representations or warranties expressed or implied, with respect to the reuse of the data provided herewith regardless of its format or the means of its transmission. There is no guarantee or representation to the user as to the accuracy, currency, suitability, or reliability of this data for any purpose. The user accepts the data "as is." The State of Minnesota assumes no responsibility for loss or damage incurred as a result of any user's reliance on this data. All maps and other material provided herein are protected by copyright. Permission is granted to copy and use the materials herein.